





FA4900
L: 4' 4"
W: 3' 10"
H: 1' 11"
232 LBS


FA4901
L: 3' 10"
W: 3' 9"
H: 2' 1"
202 LBS



FA4900
Clubhouse Roof




FA4901
Tin Roof



Exploded View

Exploded View



Hardware Detail HK063

Tree Fort Roof Post

NOTE: Read installation instructions thoroughly before starting installation process.

Step 1: Locate FA1101 Roof Posts. Bolt the Roof Posts to the Deck (See TF24 and TF24S). Do not tighten yet.

Step 2: Locate and orient the Roof per the overall plan. Bolt the roof to the Roof Posts using hardware kit HK063 in 4 places.

Step 3: Once the Roof Posts are plumb, tighten all hardware.

Included Items:

Part #	Item	Description	Quantity
Varies	Deep Woods Roof	Play Equipment	1
HK063	HDW-5	3/8" x 2-3/4" Button Head Torx Pin-in Bolt, SS	4
HK063	HDW-15	3/8" Split Lock Washer, SS	4
HK063	HDW-25	3/8" Small Flat Washer, SS	8
HK063	HDW-38	3/8" Nylock Nut	4



NOTES PRIOR TO CONSTRUCTION:

- Use appropriate equipment to lift and move the play equipment.
- Check local codes and requirements prior to digging or installing any equipment.

NOTE: Always wear eye protection appropriate to the task at hand.

**Use thread lock on all fasteners.
Cut bolt ends off with more than 2 exposed threads.**

Freestanding Roof Posts

NOTE: Read installation instructions thoroughly before starting installation process.

Step 1: Lay out the area and prepare the site for install. Concrete must be installed over a solid, level base. Check local soil condition and codes. See product installation instructions for minimum use zone requirements to ensure proper spacing and adequate surfacing area.


Step 2: Locate FA5401 Roof Posts. Place the posts on the post holes, assemble the play panels to the posts. Level and square the structure up.

Step 3: For Surface mount, locate FA5401S Roof Posts. Place the posts on concrete slab, assemble the play panels to the posts. Level and square the structure up.

Step 4: Locate and orient the Roof per the overall plan. Bolt the roof to the Roof Posts using hardware kit HK063 in 4 places.

Included Items:

Part #	Item	Description	Quantity
Varies	Deep Woods Roof	Play Equipment	1
HK063	HDW-5	3/8" x 2-3/4" Button Head Torx Pin-in Bolt, SS	4
HK063	HDW-15	3/8" Split Lock Washer, SS	4
HK063	HDW-25	3/8" Small Flat Washer, SS	8
HK063	HDW-38	3/8" Nylock Nut	4



NOTES PRIOR TO CONSTRUCTION:

- Use appropriate equipment to lift and move the play equipment.
- Check local codes and requirements prior to digging or installing any equipment.

NOTE: Always wear eye protection appropriate to the task at hand.

**Use thread lock on all fasteners.
Cut bolt ends off with more than 2 exposed threads.**